

harman/kardon

SOFTWARE UPGRADE INSTRUCTIONS

SB 26
August 2014

Harman Kardon is pleased to offer this product upgrade, which improves the performance of your Soundbar.

This Software Upgrade Improves the Following:

- Volume step improved.

Important Note

This software is specially designed for use with Harman Kardon SB 26 Soundbar. Use with any other models or brands may cause damage to the product.

DO NOT USE THIS SOFTWARE WITH ANY OTHER PRODUCTS.

How can I tell if my Sound bar needs this Upgrade?

- This software upgrade is the following MCU version: 25

To see if its software requires an upgrade, please follow these steps:

1. Connect SB 26 to a TV via HDMI TV connector.
2. Power ON SB26 and press the “**Volume +**” and the “**Bluetooth**” buttons simultaneously.
3. The software version will display on TV.
4. If the software MCU version shown is “25”, your Sound bar has the latest software version already, and no further action is needed
5. If the TV shows a version lower than this, please proceed and carry out the upgrade according to the installation instructions.

System requirements:

To install the software upgrade, you will need to UNZIP the software ZIP file and place it in the main “root” of a USB memory stick with at least 256Mb of available storage capacity. We recommend that no other files are in the main “root” directory of the memory device. If the root directory does contain any existing files, we recommend that you either remove them or save them to a separate folder on the memory stick.

INSTALLATION INSTRUCTIONS

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE PROCEEDING.

Upgrading your Sound bar is easy, but for the upgrade to work properly, it is important to carefully follow the instructions below. The upgrade will take less than 2 minutes, and once it begins you must complete the entire process in one session.

Please allow sufficient time to complete all the steps.

Attention: Do not power OFF the Sound bar or use any of its controls while software is upgrading!

1. Place the SB26 in standby mode – power LED is amber.
2. Insert the USB stick, with the software file, into the USB input: **FW UPGRADE**, on the back panel.
3. Press the “Power” button on the SB26 to power ON the unit – the power LED shortly lights white, then flashes Amber.
4. Press the “Surround” button on the SB26.
5. SOFTWARE UPGRADE begins – during upgrade the power LED turns white, surround and Bluetooth LEDs flashes.
6. When software upgrade is finish, the power LED flashes amber.
7. Unplug the USB stick.
8. The SB26 will power ON automatically (power LED turns white) - the software update is complete.

Note: If power LED flashes white and amber, the upgrade has failed – check the upgrade file and upgrade again.

Congratulations, your Sound bar is now upgraded to the latest software version.